



Exit Hardware Trim Escutcheon

**Notes**

- 1 Also see the G07 Template — *Installation Template for EXG, EXBV, and EXZ Exit Hardware Trim for Use with Von Duprin 98/99 Series Exit Devices.*
- 2 Allow plus tolerance for clearance per ANSI A115.5. The general tolerance is ± 1/64".
- 3 Use the Von Duprin 98/99 Series Lock installation instructions for backset dimensions.
- 4 Drill only for the EV function, which requires a cylinder.
- 5 For rim and vertical rod devices, drill this hole through the door; for mortise devices, drill this hole from the outside into the mortise cavity only.
- 6 Other mounting height requirements may apply.

Title Installation Specification for EXG, EXBV, and EXZ Exit Hardware Trim for Use with Von Duprin 98/99 Series Locks				<b>BEST ACCESS SYSTEMS</b>		
Series EXG, EXBV, EXZ	Backset See note 3	Trim style DV, MS, PM, PH, SC, KP	Door thickness 1 3/4" – 2 1/4"	Rev date 02/2017	Template number <b>G09</b>	Rev <b>C</b>